Sound Anchors Martin Logan CLS Stands Assembly Instructions

Thank you for purchasing Sound Anchor stands for your Martin Logan CLS loudspeakers. If these instructions are followed your Sound Anchor stands will do a great deal to enhance your enjoyment of music.

Inventory

```
Stand Weldments (2)
Side Braces (2)
Spikes (6)
1/4-20 X 1 Socket Head Cap Screws (4)
1/4-20 X 1 3/4 Socket Head Cap Screws (8)
1/4-20 X 1 1/2 Socket Head Cap Screws (2)
1/4 Flat washers (18)
Wood Screws (4)
3/16 Hex Key (1)
Aluminum side braces (4)
Wood Screws (4)
Jam Nuts (6)
3/8" Flatwashers (6)
```

If any of these parts are missing please call Sound Anchors at (321) 724-1237.

- 1. Remove the transformer from the electrostatic panel.
- 2. Place the transformer into the stand weldment as shown in Fig 1 and fasten in place using (1) 1/4-20 X 1 1/2 Socket Head Cap screw and flat washer. Tighten 2 turns beyond finger tight using the hex key provided.
- 3. Place the panel face down on a carpeted surface.
- 4. Place the stand front down and line up the mounting holes with those on the panel and fasten using (4) 1/4-20 X 1 3/4 Socket Head Cap Screws and flat washers.

Tighten firmly using the hex key provided.

- 5. Install (3) spikes into the threaded holes in the stand.
- 6. Install washers and jam nuts on each spike.
- 7. Set the speakers and stands upright in their desired location. Adjust system level with the spikes then tighten the jam nuts to lock the spikes into position
- 8. Follow the same procedure for your other speaker.

You may now set your speakers in their desired locations and Call the project finished and start listening if you wish. If you want still more performance from your system and are willing to drill two small holes in your speaker frames you will want to install the side braces on your speakers.